**USER MANUAL** 

## **BIWY Parmhood Type**

**Assembly time:** 7 minutes



**WARNING:** The bivvy must be assembled/disassembled with the door open. Failure to take this note into account could lead to irreversible damage to your bivvy (breakage/tears) and would instantly void the warranty.

## SHELTER ASSEMBLY INSTRUCTIONS:

1. Unfold the bivvy and fit the four hoops together.

2. Connect the bases of the hoops together using the straps so as to put the entire frame in compression. Use the carabiners provided for this purpose.

3. Position yourself at the rear of the bivvy and position the tension bars starting from front to back so that they keep the hoops between them taut.

4. Position the shelter in the desired location.

5. Then close the door.

6. Secure the bivvy to the ground using the twist pegs, respecting all anchor points. We recommend that you systematically use the elastic loops (by passing the head of the sardine through them) in order to improve the tension of the canvas and relieve the seams (especially in the event of wind).

7. Position the floor mat inside using the Velcro strips provided for this purpose.

## ASSEMBLY INSTRUCTIONS FOR THE OVERWRAP:

1. Unfold the overwrap and pass it over the bivvy.

2. Start by fixing it to the rear of the bivvy using the same pegs as those used to fix the bivvy itself to the ground. As with the bivvy, we recommend that you systematically use the elastic loops (by passing the head of the pegs through them) in order to improve the tension of the canvas and relieve the seams (especially in the event of wind).