

# Carp Design Intelligent Remote Control Bait Boat



## Product Operation Instruction (Item reference: 213078)



## **I. Precautions for use<sup>1</sup>**

- 1. Every time before using, you shall check functions of the boat. make sure to clean it after each use. After using, open the battery cover to check if the battery compartment has any water in it, ventilate the boat in a dry place, and keep the inside of the boat dry.**
- 2. In use, before the boat is placed into the water for operation, make sure that the boat power and remote control power has been turned on. In addition, the spare battery of the remote controller shall be equipped with at any time to prevent the boat from failing to return in case of no power of the remote controller.**
- 3. When Four-cell power alarm indicator of the boat is turned off, please stop operation and charge the boat battery or change the battery.**
- 4. The power indicator of the remote controller will gradually change from green to red during use. When the power of the remote controller is low, the power indicator will start to flicker and give out “Didi” sound. Please replace the batteries of the remote controller .**
- 5. After a new boat is received, if the power is low, please charge the batteries firstly, then use the boat. Each time after the boat batteries are used, they shall be charged fully for storage. If they**

are not used for a long time, the batteries shall be taken out and be placed in a dry and ventilated place. And the batteries shall be charged again every 2-3 months.

6. Do not use this boat in the water areas with plentiful waterweeds. If the boat propeller is wound by the fish wires, please stop using the boat immediately. After the fish wires are removed, the boat can be used again. When the fish wires are dragged, do not move back for a long time to prevent fish wires from winding in the propeller.
7. When the boat is in the course of posting and transportation, place the lithium batteries in the designed foam packing slot and fix them. Do not directly place the batteries into the boat for transportation.
8. Do not use this bait boat in bad weather, such as lightning, storms and strong wind and big waves.
9. Pls keep the remote controller in dry, and keep away from the rain and water.
10. The valid distance of the remote controller signals is 400m. Please operate the boat within the range of visibility during operation.
11. Pls contact the customer service for water seal replacement annually.
12. This product has been granted with the state utility model and

appearance patent, and its brand trademark has been registered.

Do not infringe our trademark. Once any infringement is discovered, we will investigate related legal responsibilities.

## Operation guidance

### 1. Boat installation and operation instruction



## 2. Remote controller installation and operation instruction



### I. Warranty notes

1. The valid warranty period of our whole nesting boat is 1 year and the valid warranty period of the battery pack is 6 months. The valid warranty period is counted since an effective sales voucher is provided.
2. If the warranty period of the product expires, we will provide lifelong paid repair for customers.
3. We will provide free after-sale service during the warranty period.

### Upgradable configurations

A user can select to install the following accessories according to personal preferences.

GPS auto-pilot function

Godio Fishing finder(Used on cell-phone or tablet PC)