

USER MANUAL

BIWY Type Cook House

Assembly time: 5 minutes

Difficulty level :



WARNING: The bivy must be assembled/disassembled with the door open. Failure to take this note into account could lead to irreversible damage to your bivy (breakage/tears) and would instantly void the warranty.

SHELTER ASSEMBLY INSTRUCTIONS:

1. Unfold the shelter and fit the two poles (a) together, starting at one of the two ends.
2. Connect the bases of the masts using the strap so as to put the entire frame in compression. Use the carabiners provided for this purpose.
3. Position the shelter in the desired location.
4. Position the roof stiffener (b) so that it maintains tension between the masts.
5. Position the side stiffeners (c) so that they increase the tension between the masts and tighten the canvas.
6. Position the floor mat (d) inside using the Velcro strips provided for this purpose.
7. Secure the shelter to the ground using the twist pegs, respecting all anchor points.
8. For models equipped with elastic loops, we recommend that you systematically use the elastic loops (by passing the head of the sardine through them) in order to improve the tension of the canvas and relieve the seams (especially in the event of wind) .
9. If you wish to put the awning in place, open the front door (e), pass the tips of the masts (f) through the eyelets (g) on the door provided for this purpose then tighten the straps (h) which you will fix to the ground using a peg.

ASSEMBLY INSTRUCTIONS FOR THE OVERWRAP (optional):

1. Unfold the cover and pass it over the bivvy.
2. Start by fixing it to the rear of the bivvy using the same pegs as those used to fix the bivvy itself to the ground. As with the bivvy, we recommend that you systematically use the elastic loops (by passing the head of the sardine through them) in order to improve the tension of the canvas and relieve the seams (especially in the event of wind).