

# **DARKNESS BITE ALARM SET**



## **OPERATING INSTRUCTIONS**

### 1. FEATURES FOR TRANSMITTER

- Changeable LED color bite alarms
- Adjustable Sensitivity, Volume, Tone button
- ON/OFF button (press V for 5 seconds)
- Press button S for 5 seconds to change LED light color
- 256 Variable code enough to prevent interference from another angler
- High visibility LED latching about 30 seconds
- LED Alarming signals with high output speaker
- Separate battery compartment
- Extra jack for illuminated swinger

### 2. FEATURES FOR RECEIVER

- 100m plus transmission range
- Removeable antenna
- 6 different color LEDs to match 6 different alarms
- ON/OFF, Adjustable Volume, Vibration button
- Vibration, LED Alarming signals with high output speaker
- Separate battery compartment
- Memory LED
- Night light

### 3. ALIMENTATION

The bite alarm and receiver both operates on a 9V battery.

Slide out the battery cover at rear of the alarm and insert one piece of 9v battery, ensuring the correct polarity and connection. As the battery is connected you will hear beeps and LEDs will flash, then slide back the battery cover

into place.

Always have the alarm switched off when replacing or change battery. Alkaline battery is greatly recommended for maximum battery life.

Change the battery immediatly if one of the parts fell into water.

This unit is not waterproof but can withstand droplets of water (ex. Light rain).

Take out the battery before storing for a longer period of time, this will ensure a longer life and durability for the battery.

Make sure the unit is switched off before changing or removing the battery.



#### TRANSMITTER

- (a) ON/OFF, Volume control
  - (b) tone control
  - (c) sensitivity control, button to change LED light color
  - (d) extra jack for illuminated swinger, fit size 2.5mm plug
- \* press button S for 5 seconds to change the LED light color

#### RECEIVER

- (e) removeable antenna
- (f) ON/OFF button
- (g) volume control
- (h) vibration control

The default transmitter and receiver has been connected, please don't press "ID Code" button if not necessary, it may cause the transmitter and receiver disconnected.

#### 5. INTERCHANGEABLE LED LIGHT

Press the button S on the bite alarm for 5 seconds.

The LED light color can be changed to red/yellow/blue/green/light blue/light green/purple

The LED light on the receiver will be changed in the meantime

So you can make each bite alarm with customized LED light color

#### 6. MATCH WIRELESS TRANSMITTER AND RECEIVER

When the transmitter and receiver does not match each other, or add more transmitter to match receiver, please find the ID Control button on the receiver (g) + (h) and follow the step:

- Turn on the transmitter and receiver
- Keep pressing the button V (g) and "vibration" button (h) together over 5 seconds, till the receiver beep
- To roll and actuate the bite alarm, then the receiver wil receive the signal and indicating LED on the start flashing
- The transmitter and receiver has been connected